Resettable Combination Lock
Models #'s – 22295, 33395, 30095, 77795, 3095
Operating & Resetting Instructions

The resettable combination lock is a durable and easy-to-use lock providing resettable combination access without the need for keys. ***Please read this entire page before use.***



The lock has a four (4) digit combination setting. When the lock is locked (closed), a red indicator appears in a window above the operation knob. When the lock is unlocked (open), a green indicator appears in the window.

There are two (2) modes of operation: fixed combination or resettable combination. In fixed combination mode, after a custom combination is set, the lock is continuously opened and closed with the same combination. In the resettable combination mode, the combination may be changed after each time the lock is opened.

The factory preset combination is 0000. Master key operation may be used at any time to open a lock.

Setup for a Fixed Combination

1. If locked, turn the four (4) dials to the factory preset combination or the known combination that unlocks the lock.

2. Turn the operation knob clockwise 180° to the open position. The indicator in the window will turn from red to green.

3. Turn the reset/fix stem on the back of the lock from the "Fix" to the "Reset" position.

4. Returning to the front of the lock, set the desired custom fixed combination on the four (4) dials.

5. On the back of the lock, return the reset/fix button back to "Fix".

The lock is now set to continuously open using the desired custom fixed combination. After locking, scrambling the four (4) dials will secure the contents.

Setup for a Resettable Combination

1. If locked, turn the four (4) dials to the factory preset combination or the known combination that unlocks the lock.

2. Turn the operation knob clockwise 180° to the open position. The indicator in the window will turn from red to green.

3. Turn the reset/fix stem on the back of the lock from the "Fix" to the "Reset" position. Leave the button in this position.

4. Close the door. Do not lock it.

The lock combination can now be resettable by the user setting their own desired combination before turning the operation knob to the locked position (red window indicator). After locking, scrambling the four (4) dials will secure the contents.



Decode Operation

Used to determine lock combination.

1. Open the door. Use the master key if necessary.

2. Push the decode lever to the side and hold it in place. Rotate each of the dials on the front of the lock until it stops or there is a "click" sound. Release the decode lever.

3. Each dial will now be in the "open" combination position.